

FDNL-CPG88-T-V



FDNL-CPG88-T-V

- Advanced DeviceNet[™] Station
- · Eight Combined Input and Output Points

Applications

- For Wet or Dry Environments
- For Use With Part Vertification Arrays, Three-Wire sensors, or Discrete Actuators

Features

- PNP Short-Circuit Protected Inputs with Open-Circuit Protection
- 0.5 Amp Short-Ciruit Protected Outputs with Open-Circuit Protection
- · Rotary Address Switches


This station provides eight inputs and eight outputs. The input and output circuits are combined in one connector. The unit is specifically designed to work I/O devices that have both an input and output.

Each connector has both input LED and ouput LED associated with it. The LED turns green if the I/O point is on. The LED turns red if the I/O point is shorted. The input LED turns amber if an open circuit between V+ and V- is detected. The output LED turns amber if there is open circuit between Output and V-. Open circuit detection must be enabled using a software configuration tool.

The node address can be set using the rotary switches located under the device cover or through software node commissioning. The unit automatically detects the communication rate.

The FDNL-CPG88-T-V supports explicit messaging, poll, change of state, and cyclic I/O messages. These connections are established through UCMM or predefined master/slave connection set.


Dimensions






FDNL-CPG88-T-V

Connectors



Combined Input/Output Connectors



I/O Data Mapping

Item Number: F2014 Product Code: 7/1329 (531 hex)

	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	0	I-7	I-6	I-5	I-4	I-3	I-2	I-1	I-0
Input Data	1	ISS-7	ISS-6	ISS-5	ISS-4	ISS-3	ISS-2	ISS-1	ISS-0
Output Data	2	IOS-7	IOS-6	IOS-5	IOS-4	IOS-3	IOS-2	IOS-1	IOS-0
Data	3	OS-7	OS-6	OS-5	OS-4	OS-3	OS-2	OS-1	OS-0
	4		APS						
Output	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data	0	O-7	O-6	O-5	O-4	O-3	O-2	O-1	O-0

Abbreviations

I = Input Data (0=OFF, 1=ON)

O = Output Data (0=OFF, 1=ON)

ISS = Input short Status (0=Working, 1=Fault)

OS = Output Status (0=Working, 1=Fault)

IOS = Input Open Status (0=Working, 1=Fault)

OGS = Output Group Status (0=Working, 1=Fault)

IGS = Input Group Status (0=Working, 1=Fault)

APS = Aux Power Status (0=OFF, 1=ON)



FDNL-CPG88-T-V

	Eight Combinted PNP Inputs and 0.5A Outputs, Per Point Diagnostic		
Supply Voltage			
Bus Power	11-26 VDC		
Internal Current Consumption	<100 mA Plus Sum of Sensor and Output Currents		
Input Circuits	(8) PNP 3-wire sensors or dry contacts		
Input Voltage (V+)	11-26 VDC		
Open Circuit Current (V+)	<1 mA		
Sensor current (V+)	<120 mA Per Input, Short-Circuit Protected		
Input Signal Current (Input Signal(OFF <2 mA		
	ON 3.0-3.4 mA at 24 VDC		
Maximum Switching Frequency	100 Hz		
Output Circuits	(8) DC Actuators or Indicators		
Output Voltage	18-26 VDC Optically Isolated		
Output Load Current	0.5 A Per Output		
Open Circuit Current	<1 mA Per Output		
Maximum Switching Frequency	100 Hz		
I/O LED Indications			
	Amber = Open-Circuit		
	Off = Off		
	Off = Off		
Iodule Status LED	Off = Off Green = On		
lodule Status LED	Off = Off Green = On Red = Short-Circuit Green = Working Properly		
lodule Status LED	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate		
	Off = Off Green = On Red = Short-Circuit Green = Working Properly		
Network Status LED	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate		
	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate		
	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit		
	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection		
	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection		
	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection Flashing Red = Connection Time-Out		
Network Status LED	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection Flashing Red = Connection Time-Out Red = Connection Not Possible Via Rotary Switch		
Network Status LED Adjustments	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection Flashing Red = Connection Time-Out Red = Connection Not Possible		
Network Status LED Adjustments Address	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection Flashing Red = Connection Time-Out Red = Connection Not Possible Via Rotary Switch 0-63 Via Rotary Switch		
Adjustments Address Communication Rate	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection Flashing Red = Connection Time-Out Red = Connection Not Possible Via Rotary Switch 0-63 Via Rotary Switch		
Adjustments Address Communication Rate Housing	Off = Off Green = On Red = Short-Circuit Green = Working Properly Flashing Green = Detecting Autobaud Rate Flashing Red = I/O Short-Circuit Green = Established Connection Flashing Green = Ready For Connection Flashing Red = Connection Time-Out Red = Connection Not Possible Via Rotary Switch 0-63 Via Rotary Switch Auto/125k/250k/500k		

TURCK Inc. 3000 Campus Drive Minneapolis, MN 55441 Application Support: 1-800-544-7769 10240449 Rev 1.0 06/07