## **Additional Accessories**

### XTPAXSR



**Contact Sequence** 



### **Shunt Release**

| Siluit Helease |                                  |  |  |
|----------------|----------------------------------|--|--|
| Pkg.<br>Qty. ① | Screw Terminal<br>Catalog Number |  |  |
| 2              | XTPAXSR24V50H                    |  |  |
| 2              | XTPAXSR48V50H                    |  |  |
| 2              | XTPAXSR110V50H                   |  |  |
| 2              | XTPAXSR120V60H                   |  |  |
| 2              | XTPAXSR208V60H                   |  |  |
| 2              | XTPAXSR220V50H                   |  |  |
| 2              | XTPAXSR230V50H                   |  |  |
| 2              | XTPAXSR240V50H                   |  |  |
| 2              | XTPAXSR240V60H                   |  |  |
| 2              | XTPAXSR380V50H                   |  |  |
| 2              | XTPAXSR400V50H                   |  |  |
| 2              | XTPAXSR415V50H                   |  |  |
| 2              | XTPAXSR440V60H                   |  |  |
| 2              | XTPAXSR480V60H                   |  |  |
| 2              | XTPAXSR24VDC                     |  |  |
| 2              | XTPAXSR48VDC                     |  |  |
| 2              | XTPAXSR60VDC                     |  |  |
| 2              | XTPAXSR110VDC                    |  |  |
| 2              | XTPAXSR125VDC                    |  |  |
| 2              | XTPAXSR220VDC                    |  |  |
| 2              | XTPAXSR250VDC                    |  |  |
|                |                                  |  |  |

Can be used to trip the manual motor protector from a remote location. Can be fitted on the left side of manual motor protectors. Cannot be combined with the XTPAXUVR. DC: Intermittent operation 5 sec.

### XTPAXUVR



**Contact Sequence** 



### **Undervoltage Release**

| Pkg.<br>Qty. ① | Screw Terminal<br>Catalog Number |
|----------------|----------------------------------|
| 2              | XTPAXUVR24V50H                   |
| 2              | XTPAXUVR24V60H                   |
| 2              | XTPAXUVR48V50H                   |
| 2              | XTPAXUVR60V50H                   |
| 2              | XTPAXUVR110V50H                  |
| 2              | XTPAXUVR120V60H                  |
| 2              | XTPAXUVR208V60H                  |
| 2              | XTPAXUVR220V50H                  |
| 2              | XTPAXUVR230V50H                  |
| 2              | XTPAXUVR240V50H                  |
| 2              | XTPAXUVR240V60H                  |
| 2              | XTPAXUVR380V50H                  |
| 2              | XTPAXUVR400V50H                  |
| 2              | XTPAXUVR415V50H                  |
| 2              | XTPAXUVR440V60H                  |
| 2              | XTPAXUVR480V60H                  |
| 2              | XTPAXUVR600V60H                  |

Can be used to trip the manual motor protector from a remote location. Can be fitted on left side manual motor protectors. Cannot be combined with XTPAXSR. When combined with a circuit breaker, it can be used as emergency-stop device to IEC/EN 60204.

# XTPAXCL

### **Current Limiter 2**



| Description  | Contact<br>Sequence | Pkg.<br>Qty. ① | Catalog Number |
|--|---------------------|----------------|----------------|
| To enhance the switching capacity of non-inherently safe 10–25A manual motor protectors to 150 kA/440V |                     | 1              | XTPAXCL        |


The XTPAXCL enhances the switching capacity of the XT manual motor protectors. It can be used with the XTPB, XTPR...BC1, XTPR...DC1 for individual or group protections. The rated uninterrupted current is 63A for IEC and 25A for UL/CSA. It can be mounted next to or behind the manual motor protector. See **Page V5-T1-179** for ratings when using the current limiter.

#### Notes

- $^{\scriptsize \textcircled{\scriptsize 1}}$  Orders must be placed in multiples of package quantity listed.
- ② Max. rated operation voltage U<sub>e</sub> = 690V, rated uninterrupted current I<sub>u</sub> = 63A. Can be used for individual and group protection. For group protection and in combination with the XTPR...D order additional XTPAXIT incoming terminal if required. Mounting next to or behind the manual motor protector. 16–63A XTPR...D: 100 kA/400V, 10 kA/690V.

## **Catalog Number Selection**

## **XT DC Contactors**



## **Product Selection**

## Frame M DC

## Two-Pole Contactors, Frame M—UL/CSA Ratings



| Thermal Current (I <sub>th</sub> )<br>Ampere Rating | Voltage | Article<br>Number | Auxiliary<br>Contacts | Catalog Number ① |
|---|---------|-------------------|-----------------------|------------------|
| 300   | 1000    | 183314            | 2NO-2NC               | XTCE300DCM22A    |
| 400   | 1000    | 186872            | 2NO-2NC               | XTCE400DCM22A    |
| 500   | 1000    | 186873            | 2NO-2NC               | XTCE500DCM22A    |
| 600   | 1000    | 183315            | 2NO-2NC               | XTCE600DCM22A    |

### Note

① Does not include lugs.