



A

B


C

D


E



DE Shaft End



Main terminal box



Bearing cap									
Mounting NEMA F-1									
Mounting B34R(D)									